


# BRAVEN®



## BRV-360™

WATERPROOF PORTABLE BLUETOOTH® SPEAKER  
USER MANUAL

# GET TO KNOW YOUR BRV-360

POWER ON / OFF

PLAY / PAUSE  
ANSWER / END CALL



POWER STATUS LED

BLUETOOTH PAIRING  
VOICE CONTROL

BATTERY LEVEL INDICATOR LED  
Green = 50-100% Yellow = 20-50% & Red = 0-20%

VOLUME DOWN  
SKIP BACK (press and hold)

VOLUME UP  
SKIP FORWARD (press and hold)



MIRCO-USB  
CHARGING PORT

3.5 MM INPUT

EXTERNAL USB  
CHARGING PORT

I/O PORT COVER  
(remains attached, must be secured tightly  
to speaker for waterproofing)

# POWER AND BLUETOOTH® PAIRING

---

1. Press the Power button for 2-3 seconds to turn your BRV-360 on & off.
2. Activate Bluetooth® in the settings of your mobile device (check the user manual of your device for further instruction).
3. Press and hold the Bluetooth® pairing button for 2-3 seconds until the audio cue signals.
4. Select BRV-360 in your device's Bluetooth® settings to establish the connection.
5. If your device requests a passcode to connect, enter "0 0 0 0".
6. Cancel Bluetooth® pairing mode by pressing the Bluetooth® button until the audio cue signals.

Your BRV-360 remembers the last eight devices it paired with. Tap BRV-360 in your Bluetooth® device menu to reconnect.

NOTE: If your BRAVEN is powered on with an inactive Bluetooth® connection for 30 minutes, it will automatically power off. Turn your BRAVEN on again by holding the power button for 2-3 seconds until you hear the audio cue.

# VOLUME AND PLAY BACK CONTROL

---

Increase volume by short pressing the "+" button or decrease volume by pressing the "-" button. An audio cue will indicate when you've reached max volume.

Skip to the next track by long pressing the "+" button or play the previous track by long pressing the "-" button.

# CHARGING YOUR BRAVEN

---

Before using your BRV-360 for the first time, fully charge your speaker until the battery indicator light turns green.

Charge your BRV-360 by inserting the included micro-USB cable into a wall adapter or computer. Next, plug the cable into the charging port on the back of the BRV-360.

# CHARGING EXTERNAL DEVICES

---

Your BRAVEN can charge most USB enabled smartphones and tablets using the 1A full-sized USB Port.

To use external charging:

1. Turn your BRAVEN on.
2. Plug your USB power cable into the USB portion the back of your BRAVEN.
3. Insert the other end of the cable into your device to immediately begin charging.

# SPEAKERPHONE

---

Press the "Play" button once on your BRAVEN to answer and end calls over the speakerphone.

# WATERPROOF FEATURES

---

The BRV-360 is IP67 waterproof certified and designed to withstand rainfall, waterjets, splashing or dunks in 3ft / 1m of water for up to 30 minutes.

**IMPORTANT:** Ensure your BRV-360 is prepared for use in a wet environment by removing all cable connections and tightly sealing the port cover. If the cover is not securely fastened, your BRAVEN may sustain water damage.

# USING BRAVEN VOICE CONTROL

---

Use your smartphone's virtual personal assistant by double pressing the Bluetooth® button on your BRAVEN. Give a command through the speaker to make calls, dictate messages and more.

# RESETTING YOUR BLUETOOTH® CONNECTION

---

Reset the Bluetooth® pairing list to your BRV-360 by press and holding the “+” button and “-” button for 5 seconds until the speaker shuts down.

# WARNINGS, CAUTION & LEGAL INFORMATION

To reduce the risk of fire or electric shock, do not expose the BRAVEN to rain or moisture while charging. The BRAVEN should not be exposed to dripping or splashing, and objects filled with liquids, such as vases, should not be placed on or near it while being charged or charging other devices. As with any electronic products, use care not to spill liquids into any part of the product. Liquids can cause a failure and/or a fire hazard. The power supply must be used indoors only. Make no modifications to the product or accessories. Unauthorized alterations may compromise safety, regulatory compliance, and system performance, and will void the warranty. Do not place any flame sources, such as lighted candles, on or near the BRAVEN. The BRAVEN contains small parts that may be a choking hazard and is not suitable for children under age 3. Do not continue charging the battery if it does not reach full charge within the specified charging time. Overcharging may cause the battery to become hot, rupture, or ignite. If you see any heat deformation or leakage, properly dispose of the battery. Do not attempt to charge the battery in temperatures outside the range of 32°-104°F (0°-40°C). If the battery begins to leak, do not allow the liquid to come in contact with your skin or eyes. If contact has been made, wash the affected area with plenty of water and seek medical attention immediately. Do not expose the product or battery to excessive heat, including direct sunlight or fire and storage or use inside cars in hot weather, where it can be exposed to temperatures in excess of 115°F (60°C). Doing so may cause the battery and power supply to generate heat, rupture, or ignite. Using the product in this manner also may result in a loss of performance and a shortened life expectancy. Extended exposure to direct sunlight may damage the external appearance and material qualities. Do not step on, throw, or drop batteries or the power supply or device, or expose them to a strong shock. Do not pierce, crush, dent, or deform the batteries or power supply in any way. If either becomes deformed, properly dispose of it. Do not short-circuit batteries. Do not attempt to service the BRAVEN yourself. Opening or removing covers may expose you to dangerous voltages or other hazards and will void the manufacturer's warranty. To prevent risk of fire or electric shock, avoid overloading wall outlets, extension cords, or

integral convenience receptacles. Your Bluetooth® device (mobile phone, music player, tablet, laptop, etc.) must support the A2DP Bluetooth® profile in order to work wirelessly with your new BRAVEN speaker. The A2DP profile is supported by most recent mobile products with built-in Bluetooth® capability. Please refer to your device's user manual for details and instruction regarding the Bluetooth® profiles it supports. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: — Reorient or relocate the receiving antenna. — Increase the separation between the equipment and receiver. — Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. — Consult the dealer or an experienced radio/TV technician for help. CAUTION: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. FCC RADIATION EXPOSURE STATEMENT: This device complies with FCC radiation exposure limits set forth for an uncontrolled environment. This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. Lithium Battery installed is not intended to be replaced by the USER CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type. Where the MAINS plug is used as the disconnect device, the disconnect device shall remain readily operable. The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.



Correct Disposal of this product.

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased.



This product complies with California Energy Commission efficiency standards for consumer battery chargers.