

H
—
P
O
W
E
R
P
A
T
C
H

™

PORTABLE CHARGER WITH ANTI-SLIP PATCH

PLEASE READ BEFORE OPERATING THIS EQUIPMENT


HALO POWERPATCH

Thank you for choosing HALO. Innovative, fashionable and easy to use, the HALO POWERPATCH provides a powerful and universal charging source. Equipped with an anti-slip patch, the HALO POWERPATCH will stick to almost any smooth surfaced phone or phone case. The anti-slip patch can be renewed effortlessly by simply wiping down the patch with damp cloth, making it just like new! When not in use, protect the patch from dirt and dust with the included Anti-Dust Shield.

Please read the operating instructions carefully before using the HALO POWERPATCH.


TABLE OF CONTENTS

Included Items	1
Operating Instructions	2-4
Made for iPod/iPhone/iPad	5
Safety Precautions	5
Specifications	6
Warranty and Contact Information	7



INCLUDED ITEMS

- HALO POWERPATCH
- USB to Micro USB Cable
- USB to Apple Lightning Cable
- Operating Instructions



LOCATION OF CONTROLS

- 1 | Anti-Slip Patch
- 2 | Micro USB Input Port
- 3 | USB Output Port
- 4 | Power ON/OFF Button
- 5 | LED Battery Indicator
- 6 | USB to Micro USB Cable
- 7 | USB to Apple Lightning Cable

OPERATING INSTRUCTIONS

Please make sure to fully charge the HALO POWERPATCH. Prior to first use, remove the thin plastic cover attached to the anti-slip patch. This can be easily peeled off and discarded.

NOTE:

Do not discard the anti-dust shield as this is reuseable to protect the HALO POWERPATCH from dust and dirt.

Press the power ON/OFF button to display the power level on the HALO POWERPATCH. The LED battery indicator will display four solid blue lights when fully charged.

ATTACHING THE HALO POWERPATCH

Equipped with an anti-slip patch, the HALO POWERPATCH will stick to almost any smooth surfaced phone or phone case. The HALO POWERPATCH is intended to stick to the back of your devices for a hands free charge. To attach the HALO POWERPATCH to your device, simply fold down the door, face the anti-slip patch toward your device and press & hold for 5-10 seconds.

REMOVING THE HALO POWERPATCH

To remove the HALO POWERPATCH from your device, gently pull from the bottom edge. The HALO POWERPATCH can easily be peeled off and can be reapplied & reattached to different devices.


When not in use, protect the anti-slip patch from dust and dirt by closing the door attached to the patch. This door acts as a patch protector.

CLEANING ANTI-SLIP PATCH

To clean the anti-slip patch, simply wipe down with a damp cloth & let dry, making it just like new.

CHARGING THE HALO POWERPATCH

The HALO POWERPATCH operates on a rechargeable battery. First, use the USB to Micro USB Cable (included) and connect the Micro USB tip into the Micro USB input port on the HALO POWERPATCH. Next, connect the Standard USB end into your computer's USB port or a USB adapter (not included).



While charging, the LED battery indicator will illuminate. When battery is fully charged, the power indicator will display four solid blue lights. When fully charged, disconnect the USB to Micro USB Cable.

NOTE:

The Micro USB Input Charging Port located on this unit is only used for charging the internal battery of the HALO POWERPATCH.

CHARGING ELECTRONIC DEVICES

The HALO POWERPATCH comes equipped with both a Micro USB Cable & an Apple Lightning Cable.

To charge Android devices, plug the Micro USB tip of the provided cable into your electronic device. Next, plug the USB end of the Micro USB cable into the HALO POWERPATCH output port to begin charging.

To charge Apple devices, plug the Apple lightning tip of the provided cable into your electronic device. Next, plug the USB end of the Apple Lightning cable into the HALO POWERPATCH output port to begin charging.

NOTE:

If your electronic device does not have a Micro USB Input or an Apple Lightning Input, use the charging cable provided with your electronic device. To use, plug the Standard USB end of the cable into the USB Output located on your HALO POWERPATCH.

HALO POWERPATCH POWER LEVEL INDICATORS

Indicator Lights	How to Read	Amount of Charge
● ○ ○ ○	One solid light	0%-25%
● ● ○ ○	Two solid lights	26%-50%
● ● ● ○	Three solid lights	51%-75%
● ● ● ●	Four solid lights	76%-100%

MADE FOR IPOD/IPHONE/IPAD

The HALO POWERPATCH is Apple certified. "Made for iPod", and "Made for iPhone," means that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone may affect wireless performance. AirPlay, iPhone, iPod, iPod classic, iPod nano, iPod touch, and Retina are trademarks of Apple Inc., registered in the U.S. and other countries.

SAFETY PRECAUTIONS

This HALO POWERPATCH has been designed and manufactured to ensure your personal safety when used in the directed manner. Improper use can result in potential hazard.

Please read all safety and operating instructions carefully before installation and use. Keep these instructions handy for future reference.

- The HALO POWERPATCH should not be used near water or wet areas such as bathtubs, showers, bathrooms, sinks, swimming pools or basements.
- To clean, use damp cloth to gently wipe the surface of only the patch area of the HALO POWERPATCH.
- To reduce the risk of fire or electric shock, do not expose the HALO POWERPATCH to rain or moisture. Keep the HALO POWERPATCH away from dripping, splashing, or any objects filled with liquids. Do not place anything on HALO POWERPATCH.
- Keep away from heat sources, including but not limited to: open flame sources, radiators, stoves, ovens, cars, and amplifiers that produce heat.
- Do not puncture, crush or subject to mechanical shock.
- Do not disassemble .
- Unplug the charger when batteries are fully charged or not in use.
- Li-ion batteries must be recycled. Do not dispose of in the trash

SPECIFICATIONS

Model:	HPP-3000
Battery Cell Capacity:	3000mAh
Micro USB Input:	5V  1.2A
USB Output:	5V  1.0A
Dimensions:	2.25 x 4.25 x .44 inches
Weight:	3.3 oz

COMPLIANCE WITH FCC REGULATIONS

“This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.”

“Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.”

“NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

LIMITED WARRANTY

HALO INTERNATIONAL SEZC LTD warrants its products to be free from defects in material and workmanship under normal use. Conditions are as follows:

- During the first 90 days from date of purchase, HALO INTERNATIONAL SEZC LTD will repair or replace the defective product.

- HALO INTERNATIONAL SEZC LTD will, subject to inspection, repair the defective product or replace it with a new or reconditioned unit. The return must be accompanied by a Return Merchandise Authorization (RMA) number to be issued upon request, and must be shipped prepaid.

- Where applicable, all requests for warranty returns must be accompanied by a proof of purchase.

- The warranty does not extend to the electronic equipment that is used or which incorporates with any of our products and accessories. HALO INTERNATIONAL SEZC LTD shall not be held responsible for the improper use of its products.

- In no event shall HALO be liable for any incidental, special, consequential or punitive damages arising out of the use of HALO's products.

- For all questions or exchange requests, please call 888-907-6274, or email us at support@BestHALO.com

This Limited Warranty sets forth the full scope of HALO's obligations and liabilities with respect to the product. All implied warranties, including, without limitation, implied warranties of merchantability and fitness for a particular purpose, are limited to the duration of this Limited Warranty. In no event shall HALO be liable for any incidental, special, consequential or punitive damages or any damages or losses of or to electronic equipment or products that are used with any of HALO's products.



H[®]

FOR TECHNICAL SUPPORT PLEASE
EMAIL US AT:

SUPPORT@BESTHALO.COM

OR

CALL US AT: **888-907-6274**

**HALO INTERNATIONAL SEZC LTD
68 WEST BAY ROAD
GEORGETOWN, GRAND CAYMAN, KY1-1003**

WWW.BESTHALO.COM