


  
HALO®

2 IN 1 CABLE  
POWER TASSEL



OPERATING INSTRUCTIONS

## **HALO POWER TASSEL**

Thank you for choosing HALO. The HALO POWER TASSEL is a portable charger to charge your devices, but also doubles as a fashion accessory. With their beautiful leather design, this item is the perfect crossroads where fashion meets function!

Featuring 2600mAh of HALO Portable Power and the HALO 2-in-1 cable featuring both micro USB and Apple certified MFI tips to charge any device.


Please read the operating instructions carefully before using the HALO POWER TASSEL.

## **CONTENTS**

Included Items	1
Operating Instructions	3
Maintenance and Care	4-5
Safety Precautions	5-6
Specifications	6
Warranty and Contact Information	7

# INCLUDED ITEMS

- HALO POWER TASSEL
- Operating Instructions




# LOCATION OF CONTROLS

- 1 | 360° Carabiner
- 2 | Leather Tassels
- 3 | LED Battery Light Indicator
- 4 | USB Cable
- 5 | 2 in 1 Cable

# HALO POWER TASSEL POWER LEVEL INDICATORS

Amount of Charge:



Blinking Red  
0%-3%



Solid Red  
3%-30%




Solid Yellow  
30%-75%




Solid Green  
75%-100%


While Charging:



Blinking Red  
0%-30%



Blinking Yellow  
30%-75%



Blinking Green  
75%-99%



Solid Green  
Charging Complete  
100%

## OPERATING INSTRUCTIONS

Prior to first use, it is recommended to fully charge the HALO POWER TASSEL.

### CHARGING THE HALO POWER TASSEL

Plug the USB cable into a computer or an AC adapter with a USB 5V output. Battery Indicators will blink to indicate charging.

### CHARGING YOUR PERSONAL ELECTRONIC DEVICE

1. To charge Apple devices, attach the lighting tip over the Micro USB tip. Plug the lightning tip into your Apple device to begin charging.
2. To charge Android devices, plug the Micro USB adapter located underneath the lightning tip into your device to begin charging.

**NOTE:** While charging the HALO POWER TASSEL, disconnect your devices from the HALO POWER TASSEL. It is not recommend to charge your device while charging the internal battery of the POWER TASSEL.

### TURNING ON/OFF YOUR HALO POWER TASSEL

The HALO POWER TASSEL will automatically turn on and begin charging as soon as it is plugged into your personal electronic device. To preserve the battery, the HALO POWER TASSEL will automatically turn off when the electronic device is fully charged and no longer drawing power. When the HALO POWER TASSEL is manually unplugged from your device it will automatically turn off after 30 seconds.

## COMPATIBILITY



Mobile Phones



Tablets



Cameras

+ All USB  
charged  
devices

## MADE FOR IPOD/IPHONE

The HALO POWER TASSEL is Apple certified. "Made for iPod," and "Made for iPhone," means that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone, may affect wireless performance. AirPlay, iPhone, iPod, iPod classic, iPod nano, iPod touch, and Retina are trademarks of Apple Inc., registered in the U.S. and other countries.

## MAINTENANCE AND CARE

After prolonged use, the internal battery will become weak and the operation may become intermittent. When the battery is very low, the battery indicator will flash red to alert you to recharge the internal battery as soon as possible.

To maximize battery life: once the battery is fully discharged, immediately recharge (regardless of whether you plan to use this unit or not). If you do not plan to use the battery for an extended period of time (one week or longer), we recommend

that you fully charge the battery. For longer periods of storage, please recharge the battery at least every two months to maintain the battery in optimum condition.

## **SAFETY PRECAUTIONS**

This HALO POWER TASSEL has been designed and manufactured to ensure your personal safety when used in the directed manner. Improper use can result in potential hazard.

Please read all safety and operating instructions carefully before installation and use. Keep these instructions handy for future reference.

- The HALO POWER TASSEL should not be used near water or wet areas such as bathtubs, showers, bathrooms, sinks, swimming pools or basements.
- To reduce the risk of fire or electric shock, do not expose the HALO POWER TASSEL to rain or moisture. Keep the HALO POWER TASSEL away from dripping, splashing, or any objects filled with liquids. Do not place anything on HALO POWER TASSEL.
- Keep away from heat sources, including but not limited to: open flame sources, radiators, stoves, ovens, cars, and amplifiers that produce heat.
- Do not expose HALO POWER TASSEL or batteries to fire or sunshine.
- Do not puncture, crush or subject to mechanical shock.
- Do not disassemble.
- Unplug the charger when batteries are fully charged or not in use.
- Li-ion batteries must be recycled. Do not dispose of in the

trash

## SPECIFICATIONS

Model: HPT-2600

Battery Capacity: 2600mAh

Micro USB Input: 5V  1A

USB Output: 5V  1A

Dimensions (W x H x D): 1.5 inches x 9.3 inches x 1.5 inches

Weight: 164 grams

Charging Time: ~1 hour 40 minutes

Working Temperature: 0°F to 45°F

## COMPLIANCE WITH FCC REGULATIONS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

## LIMITED WARRANTY

Halo International SEZC LTD warrants its products to be free from defects in material and workmanship under normal use.

Conditions are as follows:

- During the first 90 days from date of purchase, Halo International SEZC LTD will repair or replace the defective product.
- Halo International SEZC LTD will, subject to inspection, repair the defective product or replace it with a new or reconditioned unit. The return must be accompanied by a Return Merchandise Authorization (RMA) number to be issued upon request, and must be shipped prepaid. We do not offer shipping rebates at this time.
- Warranty is void if the product has been improperly handled or misused in any way, or if the label and/or bar-coded warranty label has been removed or tampered with.
- Where applicable, all requests for warranty returns must be

accompanied by a proof of purchase.

- The warranty does not extend to the electronic equipment that is used or which incorporates with any of our products and accessories.

Halo International SEZC LTD shall not be held responsible for the improper use of its products.

- For all questions or exchange requests, please call 888-907-6274, or email us at [support@BestHALO.com](mailto:support@BestHALO.com)

This Limited Warranty sets forth the full scope of HALO's obligations and liabilities with respect to the product. All implied warranties, including, without limitation, implied warranties of merchantability and fitness for a particular purpose, are limited to the duration of this Limited Warranty. In no event shall HALO be liable for any incidental, special, consequential or punitive damages or any damages or losses of or to electronic equipment or products that are used with any of HALO's products.



FOR TECHNICAL SUPPORT PLEASE  
EMAIL US AT:

**SUPPORT@BESTHALO.COM**

OR

CALL US AT: **888-907-6274**

**HALO INTERNATIONAL SEZC LTD**  
**68 WEST BAY ROAD**  
**GEORGETOWN, GRAND CAYMAN, KY1-1003**



**WWW.BESTHALO.COM**

Designed by Halo International  
SEZC LTD. in Cayman Islands  
Patent Pending. Made in China.

